

System 106 Call-up button / Call-up button cover plate

5541 9..
5542 9..
5543 9..
5547 9..
5549 9..

GIRA
Giersiepen GmbH & Co KG
Elektro-Installations-Systeme

Industriegebiet Mermbach
Dahlienstraße
42477 Radevormwald


Post box 1220
42461 Radevormwald
Tel.: +49 2195 602 - 0
Fax: +49 2195 602 - 191

www.gira.de
info@gira.de

35/2025

Changing the call-up button


1. Open the housing and remove the mounting frame.
2. Unlock the module and remove it from the mounting frame.
3. Loosen the screws with a screwdriver (blade width 2.5 x 0.4 mm) and pull off to the front.
4. Place new call button from the front and tighten (torque: 0.3 Nm).
5. Re-mount the module in the reverse order.



Replacing the label

The label under the transparent pane can be exchanged with the included tool without a need to remove the call button.

- ⚠ Glass inspection window!**
Check that the seal is positioned correctly before inserting the inscription label and the inspection window. If required, press the seal into the correct position.



! Labels

Suitably designed labels are available from the Gira labelling service (www.beschriftung.gira.de).

